

Product Functions

01. Purify the tap water in a simple way.
02. Enjoy 3.5L of sufficient amount of water.
03. Easy to check the service life of filter by indicator filter.
04. Enjoy more clean water by applying the selective filter.
05. Improve the taste of foods by using the water as cooking purpose.

Naturife

〈Water Purifying System〉

1. Fill the white tank in the top of the water pitcher with the tap water .

2. Filled tap water will pass through the optimised premium filter.

3. Purified to clean water depending on the characteristics of the selected filter.

- ECO-Combo
Exclusive filter for Water Pitcher
(Carbon + Resin combined filter)
: For the removal of Chlorin, Organic impurities, control of water hardness and heavy metals, improving water taste.

- BIO-ALKA
Exclusive filter for Water Pitcher
(Carbon + Alkali ball combined filter)
: For the removal of Chlorin, Organic impurities, improving water taste, production of oxygen rich alkaline water.

- ALKA-UF
Exclusive filter for Water Pitcher
(UF + Alkali ball combined filter)
: For the removal of minute impurities, Bacteria, control of heavy metals and chemical, etc and production of oxygen rich alkaline water.

4. With the above system, the tap water turns into the ideal water for drinking or cooking.



Safe and Clean Water!
Water Pitcher is always with you.

WATER PITCHER

ADVANTAGE . 1

Easy to handle for filter replacement
Indicator for the longevity of the filter.
Easy to check the service life of filter.



ADVANTAGE . 2

Sensational Design

User-friendly design to put it in the fridge with Unique Design and Compact Size.



ADVANTAGE . 3

Economical Price

Able to enjoy the drinking water safely at a reasonable price of water pitcher



Enjoy the safe drinking water by this Alka-UF with Water Pitcher.

Alka-UF
with Water Pitcher



Safe & Clean water by
New filter of Water Pitcher



WACO Corp.
(OLD : Hyundai Wacotec Co., Ltd.)



WACO Corp.
(OLD : Hyundai Wacotec Co., Ltd.)

MADE IN KOREA

More Powerful water purifying.

Possible to improve the drinking water quality effectively by selectively choosing the exclusive filters for Naturife Water Pitcher depending on the water conditions. (Removing the odors and tasted of Chlorine more than 96%)

<Filter Option>



- **ALKA-UF**
Exclusive filter for Water Pitcher (UF + Alkali combined filter)
: For the removal of minute impurities, Bacterias, control of heavy metals and chemical, etc and production of oxygen rich alkaline water.



- **ECO-Combo**
Exclusive filter for Water Pitcher (Carbon + Resin combined filter)
: For the removal of Chlorin, Organic impurities, control of water hardness and heavy metals, Improving water taste



- **BIO-ALKA**
Exclusive filter for Water Pitcher (Carbon + Alkali ball combined filter)
: For the removal of Chlorin, Organic impurities, improving water taste, production of oxygen rich alkaline water

Naturife

Why use Water Pitcher?

While tap water is safe to consume, it can contain impurities, temporary water hardness, chlorine, lead, copper, Lindane (pesticide) and other impurities. They can alter the taste and appearance of tap water which can affect food and drinks.

The water filter is the most simple, convenient and economical methods of effectively reducing impurities and improving the quality of tap water



Ideal for cold drinks.



Improves the taste of tea.



Scale free appliances.



Better flavour and aroma from coffee.



Exceptional results from cooking.



Crystal clear ice.



PRE-CAUTION

Do not use where water is micro biologically unsafe or with water that has not been disinfected in the prescribed and knowing manner.

The water quality can differ from area to area in some instances one might require additional water purifying devices.

WACO Corp.
(OLD : Hyundai Wacotec Co., Ltd.)

MADE IN KOREA